

freq.intro Introduction

The **frequency response function** $H(j\omega)$ is a complex function that relates a system's input u to its output y in terms of the input's frequency content. Given a transfer function $H(s)$ (which also relates u to y), the frequency response function can be found by the substitution

$$H(j\omega) = H(s)|_{s \rightarrow j\omega}. \quad (1)$$

It can be shown that, for a system with input $u(t) = A \sin(\omega t + \psi)$, with $A, \omega, \psi \in \mathbb{R}$ being the amplitude, angular frequency, and phase of the input, and frequency response function $H(j\omega)$, the steady-state output is

Equation 2 frequency-dependent sinusoidal response

where $|H(j\omega)|$ and $\angle H(j\omega)$ are the magnitude (i.e. norm) and phase of $H(j\omega)$, respectively. There are three striking aspects of this equation:

1. the output is also a sinusoid at the same frequency as the input;
2. the output amplitude is the input amplitude scaled by $|H(j\omega)|$; and
3. the output phase is the input phase plus $\angle H(j\omega)$.

With Fourier Series and Fourier Transform representations of signals, we can consider the input to be composed of sinusoids. For LTI systems, the principle of superposition allows us to construct a corresponding output representation.

In [Lec. freq.bode](#) and [Lec. freq.nyquist](#), we introduce the two primary ways $H(j\omega)$ is plotted. [Lec. freq.nystab](#) explores what we can learn about system stability from $H(j\omega)$ and its

frequency response function

plots. Finally, we learn how the different time-domain and frequency-domain representations of a system are related

[Lec. freq.freqtime.](#)

The frequency response methods of this chapter were actually developed before root locus methods, and are equivalent in many ways. We learn these methods for two reasons: first, they give us a deeper understanding of control systems and second there are a few situations for which frequency response methods are preferred:

1. when constructing a transfer function from measurement data,
2. when designing a controller for transient and steady-state response characteristics with lead compensation (sans lag compensation), and
3. when determining the stability of a nonlinear system.