

Complex voltages + currents

It is common to represent voltage and current in circuits as complex numbers, especially when sinusoidal signals are present.

Let a voltage $v(t) = v_0 \cos(\omega t + \phi)$ be represented by

$$v(t) = v_0 \operatorname{Re} \left[e^{j(\omega t + \phi)} \right] \\ = v_0 \operatorname{Re} \left[e^{j\phi} e^{j\omega t} \right], \text{ where we have used}$$

Euler's formulas

$$\left. \begin{aligned} e^{j\theta} &= \cos \theta + j \sin \theta \\ e^{-j\theta} &= \cos \theta - j \sin \theta \\ \cos \theta &= \frac{1}{2} (e^{j\theta} + e^{-j\theta}) = \operatorname{Re} [e^{j\theta}] \\ \sin \theta &= \frac{1}{2} (e^{j\theta} - e^{-j\theta}) = \operatorname{Im} [e^{j\theta}] \end{aligned} \right\}$$

These formulas describe a vector in the **complex plane**.

We typically use (*) to convert from complex exponential representations to trigonometric ones. We often use shorthand notation with which we "drop" the $\operatorname{Re}[\cdot]$ and $e^{j\omega t}$.

The same representation is used for alternating current $i(t) = i_0 e^{j\phi}$. This representation is often called **phasor** notation. (Sometimes: $a e^{j\theta} = a \angle \theta$.)